CDP-68/207ESD/750

SERVICE MANUAL



PHOTO: CDP-750

US Model

US Model

US Model Canadian Model AEP Model UK Model E Model

CDP-750

SPECIFICATIONS

Compact disc player

System	Compact disc player		
Laser	Semiconductor laser (λ = 780 nm)		
Laser output	Max. 0.4 mW * This output is the value measure at a distance of about 1.6 mm from the objective lens surface on the Optical Pick-up Block.		
Frequency response	2 Hz - 20 kHz (±0.5 dB)		
Signal to noise ratio	More than 102 dB		
Dynamic range	More than 95 dB		
Harmonic distortion	Less than 0.003% (at 1 kHz)		
Channel separation	More than 95 dB		
Wow and flutter	Below measurable limit (±0.001% WPEAK)		

Outputs

	Туре	Output level	Load impedance	
LINE OUT	Phono 2 V jack (50 kilohms		more than 10 kilohms	
HEADPHON- ES	Stereo jack	6.6 mW (32 ohms)	_	
DIGITAL OUT (CDP-207 ESD/ 750: AEP, UK models only)	Phono jack	0.5 Vp-p (75 ohms)	75 ohms	

Genera

Power requirements

50/60Hz

Power consumption

12W

Dimensions Approx. 430 x 100 x 340 mm (w/h/d)

(17 x 4 x 13½ inches)

including projecting parts and controls

Weight Approx. 4.7kg (10 lbs 6 oz), net

Remote commander (supplied) RM -D450

Remote control system

Infrared control

Power requirements

3 V DC with two R6 batteries (size AA)

Dimensions $62 \times 20 \times 168.5 \text{ mm (w/h/d)}$

 $(2^{1/2} \times {}^{13}/_{16} \times 6^{3}/_{4} \text{ inches})$

Weight 130 g (5 oz)

including batteries

Supplied accessories

Connecting cord (2 phono plugs ←→ 2 phono plugs)	1	
Remote commander	THE PARTY OF	
R6 batteries	2	







FEATURES

- PROGRAM play for playing up to 20 selections in a desired order
- SHUFFLE play for playing the selections in a random order
- REPEAT function for a single selection, the whole disc, PROGRAM play, or SHUFFLE play. Or for a particular portion of a selection.
- Easy-to-read display window shows the track number being played, elapsed playing time, and the remaining time, and indicates the repeat play, shuffle play, auto space functions.
- Auto space function for creating a blank space of 3 seconds between each selection.
- Timer play for initiating disc play at a desired time (a commercially available timer is required).
- Index search function for quickly locating a desired part*
- * Example: A movement in a symphony. Index search can be used only for discs having index numbers. Such discs have (\(\overline{\chi_0}\)\overline{\colored}\(\overline{\chi_0}\)\overline{\chi_0}\(\overline{\chi_0}\)\overl

CONTENTS

Section	Title			Page
SPECIFICA	ATIONS .			1
		ATION		
		JT		
		YES FROM		
		URING SERVI	CING	4
D-11		JNCTION OF (
		STMENTS		
SECTION				., ,
		D WIRING BOA	ARDS	10_12
		TIC DIAGRA		
		MS		
SECTION		ODED VIEWS		
				22-25
SECTION		TRICAL PART		
	LIST.			
TOOLINE F	TOOHS:	NG		30

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK

NON THE SCHEMATIC DIAGRAMS AND IN THE
PARTS LIST ARE CRITICAL TO SAFE OPERATION.
REPLACE THESE COMPONENTS WITH SONY PARTS
WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS
MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT ĀŸANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

MODEL IDENTIFICATION - Specification Labels -

COMPACT DISC PLAYER

AC: 120V 60Hz 12W

SERIAL NO. MADE IN JAPAN

CDP-68

SONY	MODEL NO. CDP-750
COMPACT DISC PLA	YER
45 per	
SERIAL NO.	

US, Canadian model: AC: 120 V~60 Hz 12W AEP model: AC: 220 V~50/60 Hz 12W UK model: AC: 240 V~50/60 Hz 12W E model: AC: 110-120 V,220-240 V ~50/60 Hz 12 W

SAFETY CHECK-OUT


After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)



PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs a laser. Therefore, be sure to follow carefully the instructions below when servicing.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

- 1. Laser Diode Properties
 - Material: GaAlAsWavelength: 780 nm
 - Emission Duration: continuous
 Laser Output: max. 44.6 μW*
 - * This output is the value measured at a distance of about 200 mm from the objective lens surface on the Optical Pick-up Block.
- During service, do not take the Optical Pick-up Block apart, and do not adjust the APC circuit.
 If there is a breakdown in the APC circuit (including laser diode), replace the entire Optiocal Pick-up Block (including APC borad).

BESKYTTELSE AF ØJNE MOD LASERSTRÅLING UNDER SERVICE

I dette apparat anvendes laserlys. Derfor skal nedenstående instruktioner nøje følges under service.

Følg iøvrigt instruktionerne i servicemanualen.

ADVARSEL!!

Under service må øjnene ikke komme nær objektiv-linsen på den optiske pick-up enhed. I tilfælde af at det er nødvendigt at kontrollere udsendelsen af laserlys, skal det ske i en afstand af mere end 25 cm fra den optiske pick-up.

- 1. Laser-didoe data
 - Materiale: GaAlAs
 Bølgelængde: 780 nm
 Udstråling: Kontinuerlig
 - Laseroutput: Max. 0,4 mW*
 - * Målt i 1,6 mm afstand fra overfladen af objektivlinsen på den optiske pick-up enhed.
 - Klassifikation: Klasse IIIb.
- Adskil aldrig den optiske pick-up enhed under service, og juster ikke APC kredsløbet (Automatic Power Control). Hvis APC kredsløbet (incl. laserdioden) bryder ned, skal hele den optiske pick-up enhed (incl. APC printkortet) udskiftes.

LASER ADVARSEL MÆRKNING

Følgende mærkning findes indvendig i apparatet:

1. Advarsel Mærkning

CAUTION : INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.

ADVARSEL: USYMLIG LASERSTRÂLING VED ÁBBING NAR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION UNDGÅ UDSÆTTELSE FOR STRÅLING.

VAROITUS: Laite sisāltāā, laserdiodin, joka lāhettāā (nākymātōntā) silmille vaarallista lasersateilyā.

- SERVICING NOTE -

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe more than 25 cm away from the objective lens.

Flexible Circuit Board Repairing


- Keep the temperature of the soldering iron around 270°C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

LASER DIODE AND FOCUS SERCH OPERATION CHECK

- Make POWER switch on with no disc inserted and disc table closed.
- 2. Confirm that the operation indicated in Fig. A is performed while observing the objecting lens.




,3,

Fig. A


LOCATION AND FUNCTION OF CONTROLS

FRONT PANEL



AMS is an abbreveation of Automatic Music Sensor.

Remote Commander



Remote Control Operation

Once POWER is turned on, you can remotely control various functions of the player with the supplied remote commander.

Notes on the remote control

- Keep the commander away from extremely hot or humid
- case, particularly when replacing batteries.

 To avoid malfunctions, do not simultaneously depress two Avoid dropping any foreign objects inside the commander
 - or more buttons.
- The remote sensor should not be exposed to direct illumination, especially direct sunlight, because this may prevent picking up the signals from the remote commander.

Operations which cannot be performed with the remote commander

- Turning the power on and off,
 Checking the programmed selections.
 Setting or releasing auto space function.


SECTION 1 ADJUSTMENTS

ELECTR!CAL ADJUSTMENTS

- 1. Perform adjustments in the order given.
- Use YEDS-18 (Part No.: 3-702-101-01) disc unless otherwise indicated.
- 3. Use the oscilloscope with more than 10 $M\Omega$ impedance.


RF PLL Frequency Adjustment/Lock Frequency Check

Procedure:



- 1. Connect test point TP (ASY) to ground with lead wire.
- 2. Turn POWER switch on.
- 3. Connect the frequency counter to test point TP (PCK).
- 4. Adjust RV105 so that the reading on frequency counter is 4.3218 MHz ± 30 kHz.
 - (RF PLL frequency adjustment)
- Remove lead wire connecting TP (ASY) to ground.
- 6. Put disc (YEDS-18) in and press ▷ button.
- Confirm that the reading on frequency counter is 4.3218 MHz.


Adjustment Location: main board




E-F Balance Adjustment

This adjustment should be made when replacing Optical pick-up Block.


Procedure:



- 1. Connect test point TP (ADJ) and test point TP (TE I) to ground with lead wire.
- 2. Connect oscilloscope to test point TP (TEO).
- 3. Turn POWER switch on.
- 4. Put disc (YEDS-18) in and press ▷ button.
- 5. Adjust RV101 so that the traverse waveform is symmetrical above and below.
- 6. After adjustment, remove the lead wire connected in step 5.



Adjustment Location: main board




COMPONENT SIDE (FRONT)

Focus Bias Adjustment


This adjustment should be made when replacing Optical pick-up Block.

Procedure:




- 1. Connect oscilloscope to test point TP (RF) and test point TP (RFG).
- 2. Turn POWER switch on.
- 3. Put disc (YEDS-18) in and press ▷ button.
- 4. Adjust RV102 for an optimum waveform eye pattern or so that the peak is maximum. Optimum eye pattern means that shape "♦" can be clearly distinguished at the center of the waveform.

RF signal waveform



 $A = 1.2V \pm 0.2 (V_{P-P})$

Adjustment Location: main board



REFERENCE

Focus/Tracking Gain Adjustment

A frequency response analyzer is necessary in order to perform this adjustment exactly.

However, this gain has a margin, so even if it is slightly off, there is no problem. Therefore, do not perform this adjustment.

Focus/tracking gain determines the pick-up followup (vertical and horizontal) relative to mechanical noise and mechanical shock when the 2-axis device operate.

However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise when the 2-axis device operates increases.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.
- When gain adjustment is off, the symptoms below appear.

Gain Symptoms	Focus	Tracking
• The time until music starts becomes longer for STOP → DPLAY or automatic selection (144 → 1 buttons pressed. (Normally takes about 2 seconds.)	low	low or high
 Music does not start and disc continues to rotate for STOP→DPLAY or automatic selection (IIIII) buttons pressed.) 	=	low
 Disc table opens shortly after STOP→DPLAY. 	low or high	-
 Sound is interrupted dur- ing PLAY. Or time count- er display stops progress- ing. 	=	low
More poise during 2-axis device operation.	high	high

-	-	Si	

Note

Proc

1. K

(,

2. Ir

3. C (I

4. A


• I

- 8 -

he following is a simple adjustment method.

mple Adjustment -

Since exact adjustment cannot be performed, remember the positions of the controls before performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.




eep the set horizontal.

If the set is not horizontal, this adjustment cannot be performed due to the gravity against the 2 axis device.

sert disc (YEDS-18: Fifth Selection) and press PLAY button.

onnect oscilloscope to main amp board TP FEO).

djust RV103 so that the waveform is as shown the figure below. (focus gain adjustment)




ncorrent Examples (DC level changes more than n adjusted waveform)

- 5. Connect oscilloscope to main board TP (TEO).
- 6. Adjust RV104 so that the waveform is as shown in the figure below. (tracking gain adjustment)



Incorrect Examples (fundamental wave appears)


low tracking gain



high tracking gain (higher fundamental wave than for low gain)



Adjustment Location: main board




COMPONENT SIDE (FRONT)

Semiconductors Lead Layout				
CXA1081S	M5230L-A	2SB1014		
Top view/	17345678	E 8 C		
CXA1182S *** ** ** ** ** ** ** ** ** ** ** **	M5231TL	2SB1274SA 2SD1913SA		
CXD1088Q	M5290P-16 TA8406P 16 (5/4) (7/2) (8/4) 16 (5/4) (7/2) (8/4) 17 (4/5) (7/4) 16 (9/4) (7/4)	HZS9B2L RD5.1ESB		
CXD1125Q	MSC6458-17SS 64 ppn0000000000000000000000000000000000	1SS132 10E2		
CXK5816M-10L	28 15 15 15 16 16 17 16 17 18 18 18 18 18 18 18 18 18 18 18 18 18	angule		
nanovinna nuovinna nuovinna noovinna noovinna noovinna	2SC3399 2SC3402 2SC3860			
M5218P M74HC6004P μPC4570C 8 7 6 5 1 2 3 4 (Top view)	2SB1013 2SC3622AK			

Note:

• Color code or sleeving over the end of the jacket.



- : parts extracted from the component side.
- : parts mounted on the conductor side.
- indicates side identified with part number.
- →: Jumper wire connected to the ground pattern on the component side.

SECTION 2 DIAGRAMS

Ref.No.	Location
IC1	F-6
IC2	H-5
IC3	G-3
IC4	F-2
IC5	E-2
IC6 IC7 IC8 IC9	C-2 J-7 H-7 D-4 D-7
IC11	B-4
IC12	F-4
IC13	F-3
IC101	I-12
IC102	E-10
IC201	E-16
Q1	D-4
Q2	D-4
Q3	E-6
Q4	D-3
Q5	C-3
Q6	8-2
Q7	G-6
Q8	H-4
Q9	I-4
Q10	J-2
Q11	G-4
Q12	B-2
Q13	B-2
Q14	B-3
Q15	B-2
Q20	B-3
Q21	C-4
Q22	C-2
Q23	C-2
Q24	D-3
Q25	D-3
Q26	D-3
Q601	I-14
Q602	I-14
Q603	I-14
Q604	I-14
Q605	I-14
D1 D2 D3 D4 D5	D-6 D-5 D-6 D-6
D6	C-5
D7	C-5
D8	C-5
D9	C-5
D10	E-7
D11	G-7
D12	J-2
D13	E-3
D14	C-4
D105	C-5
D106	C-5
D601	1-10
D602	1-10
D603	H-10
D604	I-14
D605	I – 14
D606	I – 14
D607	I – 14

1-9

D608

2-1. PRINTED WIRIN

A

B

C

D

E

F


G

H





-10 -


IG BOARDS • See page 18 for IC BLOCK DIAGRAMS




CDP-68/207ESD/750









Note:

- All capacitors are in μF unless otherwise noted, pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/\!\!/_4\,W$ or less unless otherwise specified.
- %: indicates tolerance.
- △ : internal component.

Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Switch

Ref. No.	Switch	Position
\$251	LOADING	IN
S252	LIMIT	ON
S601-639	KEY MATRIX	
\$701	POWER	OFF
\$902	VOLTAGE SELECTOR	(110—120V) ↓
	and the same of	(220-240V)

- B+ bus.
- = : B- bus.
- e : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal conditions.
- o no mark : STOP mode
 - () : CD Playing mode
 - Voltages are taken with a VOM (50 $k\Omega/V$). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.


 Voltage variations may be noted due to normal produc-
- tion tolerances.

 Signal path.


CDP-68/207ESD/750


• IC BLOCK DIAGRAMS

CXA1182S



CXD1088Q





Description of IC101 (MSC6458)

IC101 has the following functions:

- . Digital signal output to operation key
- . Sub ${\tt Q}$ signal loading and processing
- . Fluorescent display (FLD) control
- . Servo circuit control

Pin Function

Pin No.	Pin name	1/0	Description
1	DIRC	0	Jump pulse inversion instruction during 1 track jump.
2	CLK	0	Command transfer of clock to SSP (IC2) and DSP (IC3).
3	DATA	0	Command transfer of data to SSP (IC2) and DSP (IC3).
4	XLT	0	Command transfer of latch to SSP (IC2) and DSP (IC3).
5	M-SYNC	0	Sync REC ("H" for 300msec during muting).
6	P-SYNC	0	Sync REC ("H" for 300msec when muting is off).
7	SENSE	I	SSP (IC2) and DSP (IC3) sense information.
8	SYNC ON	Ī	Sync REC ("L" in REC mode).
9	SIRSC	I	Remote control signal input.
10	SCOR	I	Q code read timing.
11	VL UP	0	Remote controller. "L" when volume is being increased.
12	ADJ	I	"L" in PLAY mode.
13	AMUTE	0	All muting. Output to DSP (IC3) MUTG.
14	DMUTE	0	Software muting. Output to digital filter (IC4) software.
15	SUBQ	I	Subcode data.
16	SQCLK	0	Subcode data read clock.
17	GFS	I	"H" when CLV is locked.
18	FOK	I	"H" when focus is on.
19	KEY0	I	Key matrix input, "H" active.
20	KEYl	I	Key matric input, "H" active.
21	KEY2	I	Key matrix input, "H" active.
22	KEY3	I	Key matrix input, "H" active.
23	KEY4	ı	Key matrix input, "H" active.
24	KEY5	I	Key matrix input, "H" active.
25	INSW	I	Loading IN SW.
26	LDON	0	Laser on/off.
27	EPS/OUTSW	1/0	Emphasis on/off (during loading). Loading OUT SW.
28	LODOUT	0	Loading motor control.

Pin No.	Pin name	1/0	Description
29	LODIN	0	Loading motor control.
30	oscı	I	Oscillator input terminal (4 MHz).
31	OSC0	I	Oscillator input terminal (4 MHz).
32	GND	-	GND terminal.
33	RESET	I	Reset input terminal. Input when power is turned on.
34	TEST	-	No connection (NC).
35	AT DOMN	-	No connection (NC).
36	TIMER	-	No connection (NC).
37	AFADJ	I	"L" in PLAY mode. CLV-S is fixed. "L" in test mode before power is turned on.
38	PLLSW	0	"L" in PLAY mode and "H" in search mode.
39	8G	-	FLD timing output.
40	7G	0	FLD timing output.
41	6G	0	FLD timing output.
42	5G	0	PLD timing output.
43	4G	0	FLD timing output.
44	3G	0	FLD timing input.
45	2G	0	FLD timing input.
46	1G	0	FLD timing input.
47	a	0	FLD segment output.
48	£	0	FLD segment output.
49	b	0	FLD segment output.
50	q	0	FLD segment output.
51	+30V	-	+30V
52	е	0	FLD segment output.
53	c	0	FLD segment output.
54	d	0	FLD segment output.
55	0	0	FLD segment output.
56	h	0	FLD segment output.
57	m	0	FLD segment output.
58	i	0	FLD segment output.
59	n	0	FLD segment output.
60	1	0	FLD segment output.
61	i	0	FLD segment output.
62	k	0	FLD segment output.
63	р	0	FLD segment output.
64	VDD	_	Positive (+) power supply (5V)

8 | 9 V | 10 6 | 11 6 | 12 | 13 | 14 6 | 18

SECTION 3 EXPLODED VIEWS AND PARTS LIST

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.
- Color Indication of Appearance Parts Example:


 (RED) ... KNOB, BALANCE (WHITE)
 †
 Cabinet's Color

 Parts' Color


The components identified by shading and mark A are critical for safety.


Replace only with part number specified.

Les composants identifiés par une trame et une marque M sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifé.




		Jack			23	
No.	Part No.	<u>Description</u> Remar	s No.	Part No.	Description Remark	S
1 2	4-917-454-01 4-922-918-01	KNOB, LOV (COP-207ESD/750:AEP,UK) PLATE, INDICATION	15 16	*4-917-634-01 4-912-939-01	DAMPER (C) CASE	_
	4-922-918-31	(CDP-68/750:US,Canadian,E)PLATE, INDICATION	17 18 19	7-685-646-79 4-886-821-01 3-568-749-00	SCREW, TAPPING SCREW, M3 CASE CUSHION, ECM	
3	4-922-921-01 X-4922-903-1 X-4922-904-1	BUTTON (POWER) (CDP-750:US, Canadian)PANEL ASSY, FRI (CDP-750:AEP, UK)PANEL ASSY, FRI	20 NT NT 21	7-682-147-01 *4-922-927-31	SCREW +BVTT 3X6 (S)	
	X-4922-905-1 X-4922-906-1 X-4922-907-1	(CDP-750:E) PANEL ASSY, FRI (CDP-68) PANEL ASSY, FRI (CDP-207ESD) PANEL ASSY, FRI	NT 22 NT 23	*4-922-914-01 3-703-680-00	PLATE, BOTTOM BRACKET, VR (CDP-68/207ESD/750:US)LABEL, CAUTION, SUB NEW UL	
5 6 7 8	*4-922-924-01 7-685-647-79 *4-922-937-01 *4-922-933-01	BRACKET, PANEL SCREW +BVTP 3X10 TYPE2 N-S CUSHION SPACER	24 25 26 27	4-885-843-02 *4-922-939-01 *4-923-565-01 3-703-079-21	(CDP-750:AEP,UK,E)LABEL, CAUTION, LASE (CDP-750:UK)CUSHION SPACER (CDP-750:UK)LABEL, CAUTION (BACK)	ER
9 10 11 12 13 14	7-685-534-19 X-4922-908-1 4-922-923-11 3-831-441-XX 4-922-920-01 *4-918-119-01	SCREW +BTP 2.6X8 TYPE2 N-S BUTTON ASSY BUTTON (AMS) CUSHION (T) BUTTON (M.C) FILTER	901 902 903 904 FLD60	*1-624-296-11 *1-624-295-11 *1-624-297-11 1-535-684-11	PC BOARD, POWER SWITCH PC BOARD, FUNCTION PC BOARD, HEADPHONE JUMPER, FILM (WITH TERMINAL) (JUMPER FLEXIBLE BOARD) INDICATOR TUBE, FLUORESCENT	
			2	22		





No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
101 102 103 104 105	*4-922-515-01 *4-922-510-01 7-685-646-79 A-4665-012-C *3-576-990-01	TABLE, DISK REINFORCEMENT SCREW +BTP 3X8 TYPE2 N-S MAGNET ASSY CUSHION		116 117 118 119 120	4-917-507-01 *4-922-516-01 7-685-552-19 0-056-028-00 4-922-511-01	SPRING (H) CHASSIS (MD) SCREW +BTP 3X25 TYPE2 N-S WASHER, PLAIN, 14 DIA. GEAR (LOADING)	
106 107 108 109 110	4-917-519-01 4-917-514-01 4-922-508-01 4-917-541-01 4-917-508-01			121 122 123 124 125 126	*4-917-523-01 4-922-512-01 4-917-522-01 7-621-759-40 7-621-770-67 4-923-541-11	COLLAR, CAM PULLEY BELT +PSW, 2.6X6 SCREW +BYTT 2.6X6 (S) SPRING	
111 112 113 114 115	7-685-535-19 4-918-669-01 4-917-515-01 *4-922-514-01 4-917-526-01	SCREW +BTP 2.6X10 TYPE2 N-S SPRING (W) ROLLER BRACKET (BU-5) SPRING, TENSION		908 909 910 M251 S251	*1-624-324-11 *1-624-325-11 *1-624-323-11 A-4608-346-A 1-571-300-11	PC BOARD, L.MOTOR PC BOARD, TRANSLATION 5 PC BOARD, IN/OUT SW MOTOR ASSY, L SWITCH, ROTARY (LOADING IN/OUT)	

(3) MD



No. Part No.	Description	emarks No. Part No.	Description Remarks
153 7-621-255-19 154 4-917-567-0	1 INSULATOR 5 SCREW +P 2X3	912 A.8-848-062-01 CNJ251*1-564-720-21 M252 X-4917-523-1 M253 X-4917-504-1	PC BOARD, SL/SP MOTOR DEVICE, OPTICS (KSS-150A) PIN, CONNECTOR (SMALL TYPE) 4P ASSY, MOTOR (SPINDLE) ASSY, MOTOR (SLED) SWITCH, LEAF (LIMIT IN)

SECTION 4 ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS: MF: μF, PF: μμF.

RESISTORS

- All resistors are in ohms.
- F: nonflammable

COLLS

MMH: mH, UH: μH

SEMICONDUCTORS

In each case, U: μ , for example: UA...: μ A..., UPA...: μ PA..., UPC...: μ PD...

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

Les composants identifiés par une trame et une marque / \(\frac{\hat{\Lambda}}{\text{Nont critiques pour la sécurité.}}\)
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	. Part No.	Description				Ref.No.	Part No.	Description			
901 902 903 904	*1-624-296-11 *1-624-295-11 *1-624-297-11 1-535-684-11	PC BOARD, PC PC BOARD, FU PC BOARD, HE JUMPER, FILM	INCTION ADPHONE			C121 C122 C123 C124	1-162-851-11 1-123-382-00 1-130-768-00 1-123-875-11	CERAMIC ELECT FILM ELECT	0.1MF 3.3MF 0.1MF 10MF	20% 20% 5% 20%	16 V 50 V 63 V 50 V
905	*A-4651-152-A *A-4651-154-A	(CDP-207ESD) (CDP-68/750:	MOUN US,Canadian	TED PCB	, MAIN	C125 C126 C127	1-124-908-11 1-162-851-11 1-124-908-11	ELECT CERAMIC ELECT	22MF 0.1MF 22MF	20% 20% 20%	25V 16V 25V
	*A-4651-155-A *A-4651-156-A	(CDP-750:AEF	,UK)MOUN		, MAIN	C128 C129 C130	1-162-851-11 1-124-499-11 1-124-499-11	CERAMIC ELECT ELECT	0.1MF 1MF 1MF	20% 20% 20%	16V 50V 50V
906	A.1-551-188-XX A.1-555-795-00 A.1-558-204-11 A.1-558-942-11	(CDP-750:UK (CDP-68/207))CORD, P	OWER, El OWER anadian		C131 C132 C133	1-161-377-00 1-124-927-11 1-124-499-11	CERAMIC ELECT ELECT	0.0047MF 4.7MF 1MF	30% 20% 20%	16V 50V 50V
			CURU, FUNE	n (ruchi	1.51 1.21	C134	1-124-477-11	ELECT	47MF	20%	164
007	A 1 FOC FCF 00	(CDP-750:E3	AC DI IIG	ADADTOR	ne navidansimi.	C135	1-162-294-31	CERAMIC	0.001MF	10%	50V
907 908 909	A.1-526-565-00 *1-624-324-11 *1-624-325-11	PC BOARD, L	.MOTOR			C136	1-162-282-31		100PF	10%	50V
303	1 02. 020 11	, ,				C137	1-162-851-11		0.1MF	20%	16V
910	*1-624-323-11	PC BOARD, I	N/OUT SW			C138	1-126-101-11		100MF	20%	167
911	*1-624-322-11	PC BOARD, SI				C139	1-126-101-11	ELECT	100MF	20%	167
	A.8-848-062-01	DEVICE, OPT		(A)		50		E. COT	0.47MF	20%	50V
	<u></u>					C140	1-124-902-00			5%	50V
C007	1-123-875-11	ELECT	10MF	20%	50V	C141	1-130-489-00	MYLAR	0.033MF 0.47MF	20%	50V
C008			10MF	20%	50V	C142	1-124-902-00	ELECT	0.4781	200	204
C009			470MF	20%	6.3V				0045	20%	25¥
C010			470MF	20%	6.31	C143	1-124-908-11	ELECT	22MF	20%	25V
0010						C144	1-124-908-11		22MF	5%	63V
C012	1-124-919-11	ELECT	220MF	20%	63 V	C145	1-130-772-00	FILM	0.22MF	5%	034
CO13			100MF	20%	50V	V			0.0145	ca	50V
CO14			4.7MF	20%	50V	C146	1-130-483-00		0.01MF	5%	50V
001	1 11 71 71					C147	1-162-199-31		10PF	5%	50V
CO15	1-124-927-11	ELECT	4.7MF	20%	50V	C148	1-162-199-31	CERAMIC	10PF	5%	201
C101			0.0022MF	5%	50V	1			0.01145	20%	161
C102			8.2PF	10%	50V	C149	1-161-379-00		0.01MF	10%	507
C103			47MF	20%	167	C162	1-162-294-31		0.001MF	5%	50V
						C163	1-130-489-00	MYLAR	0.033MF	36	301
C104	1-162-294-31	CERAMIC	0.001MF	10%	50V		4 404 400 11	EL ECT	1MF	20%	50V
C105		ELECT	4700MF	20%	161	C164			1MF	20%	50V
C106		ELECT	3300MF	20%	16V	C165	1-124-499-11	ELECT	100MF	20%	507
						C201	1-124-122-11	ELECT	TOOM	200	301
C107	1-124-477-11	ELECT	47MF	20%	16V		. 104 012 11	EL ECT	470MF	20%	50V
C10	3 1-161-375-00	CERAMIC	0.0022MF	30%	16V	C202			100MF	20%	50V
C109		MYLAR	0.033MF	5%	50V	C203	1-124-122-11		330MF	20%	50V
C110		MYLAR	0.01MF	5%	50V	C204	1-124-912-11	FLECI	SSUM	200	304
						2005	1 104 400 11	CLECT	1MF	20%	507
C11	1 1-124-908-11	ELECT	22MF	20%	25V	C205			470PF	10%	507
C11			47MF	20%	167	C208			4.7MF	20%	507
C113	3 1-162-294-31	CERAMIC	0.001MF	10%	50V	C209	1-124-927-11	ELECT	4.710	200	
						0051	1-136-157-00	CTLM	0.022MF	5%	50V
C11	4 1-162-294-31	L CERAMIC	0.001MF	10%	50V	C251			0.0022MF	5%	50V
C11	5 1-162-851-11	CERAMIC	0.1MF	20%	16V	C252			0.0022MF	5%	507
C11			22MF	20%	25V	C253	1-106-351-00) MYLAR	0.0024111	310	301
C11			47MF	20%	164	{		1000 007CC	D /760, 450 III/	`	
011						C302	1-162-203-31		D/750:AEP,UK! RAMIC 15PF	5%	50 V
C11	8 1-130-768-00) FILM	0.1MF	5%	63V	1			RAMIC 15PF O:US,Canadia		301
C11			0.033MF	5%	50V	C302	1-162-207-31		RAMIC 22PF	5%	50V
C12			0.0068MF	20%	16V	T			MARIL CEFT	32	001
CIE						F1					

Ref.No.	Part No.	Description	n		
C303	1-162-203-31		- D/750:AEP ,UK)	Market.	Time
C303	1-162-207-31		RAMIC 15PF D:US,Canadian RAMIC 22PF	5% ,E) 5%	50V 50V
C304 C305 C306	1-124-444-00 1-124-444-00 1-161-494-00	ELECT ELECT CERAMIC	220MF 220MF 0.022MF	20% 20%	6.3V 6.3V 25V
C307 C308 C309	1-161-494-00 1-161-494-00 1-161-494-00	CERAMIC CERAMIC CERAMIC	0.022MF 0.022MF 0.022MF		25V 25V 25V
C310 C311 C312	1-161-494-00 1-161-494-00 1-162-851-11	CERAMIC CERAMIC CERAMIC	0.022MF 0.022MF 0.1MF	20%	25V 25V 16V
C313 C314 C315	1-161-494-00 1-161-494-00 1-161-494-00	CERAMIC CERAMIC CERAMIC	0.022MF 0.022MF 0.022MF		25V 25V 25V
C316 C317 C318	1-161-494-00 1-161-494-00 1-161-494-00	CERAMIC CERAMIC CERAMIC	0.022MF 0.022MF 0.022MF		25V 25V 25V
C319 C320 C321	1-162-851-11 1-162-290-31 1-130-474-00	CERAMIC CERAMIC MYLAR	0.1MF 470PF 0.0018MF	20% 10% 5%	16V 50V 50V
C322 C323 C324	1-130-474-00 1-126-103-11 1-126-103-11	MYLAR ELECT ELECT	0.0018MF 470MF 470MF	5% 20% 20%	50V 16V 16V
C325 C326 C327	1-123-332-00 1-123-332-00 1-130-488-00	ELECT ELECT MYLAR	47MF 47MF 0.027MF	20% 20% 5%	25V 25V 50V
C328 C329 C330	1-130-488-00 1-106-343-00 1-106-343-00	MYLAR MYLAR MYLAR	0.027MF 0.001MF 0.001MF	5% 5% 5%	50V 50V 50V
C401	1-124-908-11		D/750: AEP ,UK)	20%	25 V
C402	1-124-908-11	EL (CDP-207ES EL	D/750:AEP ,UK)		25V
C406	1-162-851-11		D/750:AEP,UK)		167
C407	1-162-282-31	(CDP-207ES	RAMIC 0.1MF D/750:AEP,UK) RAMIC 100PF		500
C501 C502 C503 C504	1-124-443-00 1-124-443-00 1-162-290-31 1-162-290-31	ELECT ELECT CERAMIC CERAMIC	100MF 100MF 470PF 470PF	20% 20% 10% 10%	10V 10V 50V 50V
C601 C602 C603	1-124-638-11 1-124-638-11 1-123-611-00	ELECT ELECT	22MF 22MF 1MF	20% 20% 20%	6.3V 6.3V 50V
C604 C605 C606 C607	1-162-851-11 1-162-290-31 1-162-290-31 1-162-290-31	CERAMIC CERAMIC CERAMIC CERAMIC	0.1MF 470PF 470PF 470PF	20% 10% 10% 10%	16V 50V 50V 50V
CN258	*1-564-336-51 *1-564-337-51 *1-564-704-11	PIN, CONNI PIN, CONNI PIN, CONNI		TYPE) 2P	
	51*1-564-720-21)1*1-564-721-11		ECTOR (SMALL ECTOR (SMALL		
CNP10	01*1-564-340-00 01*1-564-706-31 02*1-564-710-11	PIN, CONN PIN, CONN PIN, CONN	ECTOR 6P ECTOR (SMALL ECTOR (SMALL		

8	f.No.	Part No.	Description
	CNP104	*1-564-706-41 *1-564-706-11 *1-564-339-61	PIN, CONNECTOR (SMALL TYPE) 4P PIN, CONNECTOR (SMALL TYPE) 4P PIN, CONNECTOR 5P
	CNP301	1-566-908-11 *1-564-707-11 *1-564-499-11	SOCKET, CONNECTOR 32P PIN, CONNECTOR (SMALL TYPE) 5P PIN, CONNECTOR 6P
	D2 A	.8-719-200-02 .8-719-200-02 .8-719-200-02	DIODE 10E2 DIODE 10E2 DIODE 10E2
	D5 A	.8-719-200-02 .8-719-200-02 .8-719-200-02	DIODE 10E2 DIODE 10E2 DIODE 10E2
	D8 A	.8-719-200-02 .8-719-200-02 .8-719-200-02	DIODE 10E2 DIODE 10E2 DIODE 10E2
	D10 D11 D12	8-719-109-83 8-719-940-76 8-719-940-76	DIODE RD5.1ESB DIODE 1SS132 DIODE 1SS132
	D13 D14 D105	8-719-940-76 8-719-940-76 8-719-940-76	DIODE 1SS132 DIODE 1SS132 DIODE 1SS132
	D106 D601 D602	8-719-940-76 8-719-940-76 8-719-940-76	DIODE 1SS132 DIODE 1SS132 DIODE 1SS132
	D603 D604 D605	8-719-940-76 8-719-940-76 8-719-940-76	DIODE 1SS132 DIODE 1SS132 DIODE 1SS132
	D606 D607 D608	8-719-940-76 8-719-940-76 8-719-933-57	DIODE 1SS132 DIODE 1SS132 DIODE HZS9B2L
	FLD60	1 1-519-411-11	INDICATOR TUBE, FLUORESCENT
	IC1 IC2 IC3	8-752-031-80 8-752-032-33 8-752-322-04	IC CXA1081S IC CXA1182S IC CXD1125Q
	IC4 IC5 IC6	8-759-939-35 8-759-939-94 8-759-601-02	IC CXD1088Q IC TDA1541-N5 IC M5218P
	IC7 IC8 IC9	8-759-208-96 8-759-805-18 8-759-630-21	IC TA8406P IC LA6520 IC M5290P-16
	IC10 IC11 IC12	8-759-602-66	IC M5231TL IC M5230L-A (CDP-207ESD/750:AEP,UK)IC M74HC6004P
	IC13 IC101 IC102 IC201	8-759-945-87 8-741-138-70	IC CXK5816M-10L IC MSC6458-17SS IC BX-1387
	J301 J401	1-566-921-11 1-566-922-11	(CDP-207ESD/750:AEP,UK)JACK, PIN 1P (DIGITAL OUT)
	J501	1-563-485-21	17 TO THE STREET AND THE PERSON OF THE PERSO
	L101 L401	1-408-563-00 *1-410-858-11	
	M251	A-4608-346-/	MOTOR ASSY, L
	M252 M253		
1			W.

The components identified by shading and mark A are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description		1	Ref.No.	Part No.	Description			
PS101	1-532-637-00 1-532-637-00 1-532-605-00	(CDP-750:AEP,UK,E) (CDP-750:AEP,UK,E) (CDP-750:AEP,UK,E)	LIN	K, IC	R117 R118 R119 R120	1-249-381-11 1-249-393-11 1-215-472-00 1-249-393-11	CARBON CARBON CARBON CARBON	1 10 130K 10	5% 5% 5%	1/4W 1/4W 1/4W 1/4W
PS201	1-532-605-00 1-532-685-00 1-532-685-00	(CDP-750:AEP,UK,E) (CDP-750:AEP,UK,E) (CDP-750:AEP,UK,E)	LIN	K, IC	R122 R123 R124	1-249-440-11 1-215-479-00 1-249-435-11	CARBON CARBON CARBON	82K 270K 33K	5% 5% 5%	1/4W 1/4W 1/4W
Q1 Q2 Q3	8-729-808-72 8-729-808-76 8-729-806-38	TRANSISTOR 2SB1274 TRANSISTOR 2SD1913 TRANSISTOR 2SC3399	SA		R125 R126 R127	1-249-393-11 1-249-423-11 1-249-425-11	CARBON CARBON CARBON	10 3.3K 4.7K	5% 5% 5%	1/4W 1/4W
Q4 Q5 Q6	8-729-806-38 8-729-806-38 8-729-806-20	TRANSISTOR 2SC3399 TRANSISTOR 2SC3399 TRANSISTOR 2SA1345)		R128 R129	1-249-393-11 1-249-429-11	CARBON CARBON	10 10K	5% 5%	1/4W 1/4W 1/4W
Q7 Q8 Q9	8-729-801-83 8-729-806-28 8-729-806-38	TRANSISTOR 2SB1013 TRANSISTOR 2SC3402 TRANSISTOR 2SC3399			R130 R131 R132	1-215-486-00 1-249-433-11 1-249-414-11	CARBON CARBON CARBON	510K 22K 560	5% 5% 5%	1/4W 1/4W 1/4W
010 011 012	8-729-806-38 8-729-806-38 8-729-107-99	TRANSISTOR 2SC3399 TRANSISTOR 2SC3399 TRANSISTOR 2SC3622			R133 R134 R135	1-249-441-11 1-215-434-00 1-249-441-11	CARBON METAL CARBON	100K 3.6K 100K	5% 1% 5%	1/4W 1/6W 1/4W
Q13 Q14 Q15	8-729-107-99 8-729-806-32 8-729-806-32	TRANSISTOR 2SC3622 TRANSISTOR 2SC3860 TRANSISTOR 2SC3860			R136 R137	1-249-437-11 1-249-436-11	CARBON CARBON	47K 39K	5% 5%	1/4W 1/4W
020 021 022	8-729-806-20 8-729-802-22 8-729-806-32	TRANSISTOR 2SA1345 TRANSISTOR 2SB1014			R138 R139 R140	1-249-393-11 1-249-381-11 1-249-429-11	CARBON CARBON CARBON	10 1 10K	5% 5% 5%	1/4W 1/4W 1/4W
023 024	8-729-806-32 8-729-806-20	TRANSISTOR 2SC3860 TRANSISTOR 2SC3860 TRANSISTOR 2SA1345			R141 R142 R143	1-215-493-00 1-249-433-11 1-249-441-11	CARBON CARBON	1M 22K 100K	5% 5% 5%	1/4W 1/4W
Q25 Q26 0601	8-729-806-20 8-729-806-38 8-729-806-28	TRANSISTOR 2SA1345 TRANSISTOR 2SC3399 TRANSISTOR 2SC3402		-	R144 R145	1-249-441-11 1-249-429-11	CARBON CARBON	100K 10K	5% 5%	1/4W 1/4W 1/4W
Q602 Q603	8-729-806-28 8-729-806-28	TRANSISTOR 2SC3402 TRANSISTOR 2SC3402			R146 R147 R150	1-215-469-00 1-215-469-00 1-249-429-11	METAL METAL CARBON	100K 100K 10K	1% 1% 5%	1/6W 1/6W 1/4W
Q605 R001	8-729-806-28 8-729-806-28 1-249-429-11	TRANSISTOR 2SC3402 TRANSISTOR 2SC3402 CARBON 10K	5%	1/4W	R151 R152 R153	1-249-417-11 1-249-417-11 1-249-417-11	CARBON CARBON CARBON	1K 1K 1K	5% 5% 5%	1/4W 1/4W 1/4W
R003	1-249-425-11	CARBON 4.7K CARBON 4.7K CARBON 3.3K	5% 5% 5%	1/4W 1/4W 1/4W	R154 R155 R163	1-249-417-11 1-249-429-11 1-249-438-11	CARBON CARBON CARBON	1K 10K 56K	5% 5% 5%	1/4W 1/4W 1/4W
R005 R006	1-249-431-11	CARBON 15K CARBON 62K	5% 5%	1/4W 1/4W	R164 R165 R166	1-249-424-11 1-249-429-11 1-249-417-11	CARBON CARBON CARBON	3.9K 10K 1K	5% 5% 5%	1/4W 1/4W 1/4W
R008 R009	1-249-423-11 1-249-425-11	CARBON 3.3K CARBON 4.7K	5% 5%	1/4W 1/4W 1/4W	R167 R168 R197	1-249-417-11 1-249-417-11 1-249-417-11	CARBON CARBON CARBON	1K 1K 1K	5% 5% 5%	1/4W 1/4W 1/4W
R102	1-215-450-00	CARBON 8.2K CARBON 16K CARBON 2.2K	5% 5% 5%	1/4W 1/4W 1/4W	R201 R202 R203	1-215-493-00 1-249-423-11 1-215-454-00	CARBON CARBON	1M 3.3K	5% 5%	1/4W 1/4W
R105	1-215-396-00	METAL 22 CARBON 91 CARBON 22K	1% 5% 5%	1/4W 1/4W 1/4W	R204 R205	1-249-414-11 1-249-431-11	CARBON CARBON CARBON	24K 560 15K	5% 5% 5%	1/4W 1/4W 1/4W
R108	1-249-432-11	CARBON 1K CARBON 18K CARBON 18K	5% 5% 5%	1/4W 1/4W 1/4W	R206 R301 R302	1-249-431-11 1-249-411-11 1-249-417-11	CARBON CARBON CARBON	15K 330 1K	5% 5% 5%	1/4W 1/4W 1/4W
R111	1-249-425-11	CARBON 4.7K CARBON 4.7K CARBON 1K	5% 5% 5%	1/4W 1/4W 1/4W	R303 R304 R305	1-249-417-11 1-249-417-11 1-259-434-11	CARBON CARBON CARBON	1K 1K 1.8K	5% 5%	1/4W 1/4W 1/6W
R114	1-247-881-00	CARBON 130K CARBON 120K CARBON 130K	5% 5%	1/4W 1/4W	R306 R307	1-259-434-11 1-259-488-11	CARBON CARBON	1.8K 330K	5% 5%	1/6W 1/6W
		CARBON 130K	5% 5%	1/4W 1/4W		1-259-488-11 1-259-424-11	CARBON CARBON	330K 680	5% 5%	1/6W 1/6W

Ref.No.	Part No.	Descripti	on			
R310 R311 R312	1-259-424-11 1-259-422-11 1-259-422-11		680 560 560	5% 5% 5%	1/6W 1/6W 1/6W	
R313 R314 R315	1-249-425-11 1-249-425-11 1-249-441-11	CARBON	4.7K 4.7K 100K	5% 5% 5%	1/4W 1/4W 1/4W	
R316 R319 R320	1-249-441-11 1-259-424-11 1-259-424-11	CARBON CARBON CARBON	100K 680 680	5% 5% 5%	1/4W 1/6W 1/6W	
R321 R322 R323	1-259-460-11 1-259-460-11 1-259-500-11	CARBON CARBON CARBON	22K 22K 1M	5% 5% 5%	1/6W 1/6W 1/6W	
R324 R325 R326	1-259-500-11 1-259-404-11 1-259-404-11	CARBON CARBON CARBON	1M 100 100	5% 5% 5%	1/6W 1/6W 1/6W	
R327 R328	1-259-423-11 1-259-423-11	CARBON CARBON	620 620	5% 5%	1/6W 1/6W	
R401	1-249-412-11	(CDP-207ES			(In the hand	
R402	1-215-396-00	(CDP-207ES		,UK)	1/4W	
R403	1-249-417-11	(CDP-207ES	ARBON 91 D/750:AEP ARBON 1K	5% ,UK) 5%	1/4W	
DEO1	1 250 400 11	The second	The area of		1/4W	
R501 R502 R503	1-259-428-11 1-259-428-11 1-259-460-11	CARBON CARBON CARBON	1K 1K 22K	5% 5% 5%	1/6W 1/6W 1/6W	
R504 R505 R506	1-259-460-11 1-259-450-11 1-259-450-11	CARBON CARBON CARBON	22K 8.2K 8.2K	5% 5% 5%	1/6W 1/6W 1/6W	
R507 R508 R601	1-259-404-11 1-259-404-11 1-249-435-11	CARBON CARBON CARBON	100 100 33K	5% 5% 5%	1/6W 1/6W 1/4W	
R602 R603 R604	1-249-435-11 1-249-435-11 1-249-435-11	CARBON CARBON CARBON	33K 33K 33K	5% 5% 5%	1/4W 1/4W 1/4W	
R605 R606 R607	1-249-435-11 1-249-435-11 1-249-435-11	CARBON CARBON CARBON	33K 33K 33K	5% 5% 5%	1/4W 1/4W 1/4W	
R608 R609 R610	1-249-425-11 1-249-425-11 1-249-425-11	CARBON CARBON CARBON	4.7K 4.7K 4.7K	5% 5% 5%	1/4W 1/4W 1/4W	
R611 R612	1-249-425-11 1-249-421-11	CARBON CARBON	4.7K 2.2K	5% 5%	1/4W 1/4W	
RV102	1-228-995-00 1-228-993-00 1-228-995-00	RES, ADJ, C RES, ADJ, C RES, ADJ, C	CARBON 4.7	K (FO	CUS BIAS)	
RV105	1-228-995-00 1-228-990-00 1-237-789-11	RES, ADJ, O RES, ADJ, N RES, VAR, O	METAL GLAZ	E 1K	CKING GAIN) (RF PLL) (PHONE LEVEL)	
S251 S252 S601 S602	1-571-300-11 1-571-274-11 1-554-303-21 1-554-303-21	SWITCH, ROT SWITCH, LEA SWITCH, KEY SWITCH, KEY	F (LIMIT BOARD (P	IN) ROGRAN		
	1-554-303-21 1-554-303-21 1-554-303-21 1-554-303-21	SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD (O	PEN/CL HECK)		
\$607 \$608 \$609 \$610	1-554-303-21 1-554-303-21 1-554-303-21 1-554-303-21	SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD (A	I) UTO SP		
\$611 \$612 \$613 \$614	1-554-303-21 1-554-303-21 1-554-303-21 1-554-303-21	SWITCH, KEY SWITCH, KEY SWITCH, KEY SWITCH, KEY	BOARD (CO	UNITAC (1		

R	ef.No.	Part No.		Descrip	tion				
	S615 S616 S617 S618	1-554-303- 1-554-303- 1-554-303- 1-554-303-	-21 -21	SWITCH, SWITCH, SWITCH, SWITCH,	KEY	BOARD BOARD	(1)		
	S619 S620 S621 S622	1-554-303- 1-554-303- 1-554-303- 1-554-303-	21	SWITCH, SWITCH, SWITCH,	KEY	BOARD BOARD	(4) (5)	-)	
	S623 S624 S625 S626	1-554-303- 1-554-303- 1-554-303- 1-554-303-	21	SWITCH, SWITCH, SWITCH,	KEY	BOARD BOARD	(7) (8)		
	\$627 \$628 \$629 \$630	1-554-303- 1-554-303- 1-554-303- 1-554-303-	21	SWITCH, SWITCH, SWITCH, SWITCH,	KEY KEY	BOARD BOARD	(11)	-)	
	\$631 \$632 \$633 \$634	1-554-303- 1-554-303- 1-554-303- 1-554-303-	21	SWITCH, SWITCH, SWITCH,	KEY	BOARD BOARD	(14)		
167	\$635 \$636 \$637 \$638	1-554-303- 1-554-303- 1-554-303- 1-554-303-	21	SWITCH, SWITCH, SWITCH, SWITCH,	KEY	BOARD BOARD	(17) (18)		
	\$639 \$701 \$902 ♠	1-554-303- 1-571-305- .1-571-309-	11	SWITCH, SWITCH, (CDP-750	PUSH	1 11 KE	Y) (PO	WER) OLTAGE	SELECTOR
	T901 ₼	.1-449-024- .1-449-025- .1-449-026-	11	(CDP-750 (CDP-750	:AEP	,UK)	TRAN	SFORMER SFORMER	, POWER
	X301 X301	1-567-908- 1-567-926-		(CDP-68)	ESD/	VIB	RATOR P,UK)	,E) , CRYST , CRYST	
	X601	1-567-686-	11	OSCILLAT	OR,	CERAMI	C (4M	(z)	
	ACC	CESSORY & P.	ACK I	NG MATER	RIAL				
		63-923-11 558-543-11		OTO COMM			D450)		
		665-234-00 704-346-01	(CD	P-750:E) P-68/207	B ESD/	AG, PR 750:US	,Canac	iian ,AE	P,UK) TANDARD)
		03-390-01 95-629-11	(CD	P-68/207 P-750: AE	ESD/	750:US)IN	ISTRUCT ISTRUCT	ION
	3-7 3-7 3-7	69-585-11 69-585-21 69-585-41 69-585-51 69-585-61	(CD (CD	P-750:AE P-750:US P-750:AE P-207ESD P-68)) P)	MA MA MA	NUAL, NUAL, NUAL,	INSTRU	CTION CTION CTION
		22-417-01 22-581-01		, BATTER HION	Y CA	SE (FO	R RM-D	450)	

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

4-922-517-51 (CDP-750)....INDIVIDUAL CARTON 4-922-517-61 (CDP-207ESD)...INDIVIDUAL CARTON (CDP-68)....INDIVIDUAL CARTON

Les composants identifiés par une trame et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifé.

Troubleshooting

The following checks will assist in the correction of most problems which you may encounter with your unit. Before going through the check list below, first refer back to the connection and operating procedures.

Should any problem persist after you have made these checks, consult your nearest Sony service facility.

Symptom	Cause	Countermeasures		
Play does not begin.	The disc is incorrectly inserted.	Insert the disc correctly.		
	The disc is extremely dirty.	Clean the disc.		
	The disc is inserted upside down.	Insert the disc correctly.		
	The II button has been pressed.	Press 11 button again to release pause.		
± ±	Moisture condensation.	Leave the player turned on for about an hour.		
No audio from one or both channels.	Incorrect connections.	Connect properly.		